

Red X covers the image

If a large red X appears on the monitor when you view a surface, color may not be correct. The red X can be disabled through PressProof preferences.

To determine what problem the X is warning about:

1. Press the spacebar to go to Window mode.
2. Look for color target and monitor calibration information at the bottom of the left pane.

Example of warning messages include:

- **Color target: none**- The surface does not have an assigned color target.
- **Monitor: uncalibrated**-The monitor calibration has expired and it must be successfully calibrated.
- **Pages on surface have inconsistent color targets**-Different targets are assigned to different pages on the surface.

To disable the red X:

1. On the Apple toolbar under **Kodak PressProof**, select **Preferences**.
2. Clear the check box beside **Display red X over image when color may not be correct**.

Note: If you disable the red X, a small version of it appears in the upper left corner of the screen, and blinks continuously.



You cannot disable this icon except by restoring the red X that covers the entire screen.