

Removing an SCO from a color setup

1. Click the **Color Setups** tab, and then click the desired color setup from the list to show it in the viewer window.
2. Right-click the SCO.
3. Click **Delete**.
4. Click **Yes** to confirm the deletion.