

# Software license and dongle

A valid MPI dongle and version-specific license are required. To operate the software in production mode, entitlement must be registered to the dongle ID in the Kodak Product Registration and Activation System (PLAS).

Upgrade notes:

- Licenses for upgrades are backward compatible.
- If upgrade entitlement is available as part of a service contract, you can download the license file for the latest available upgrade version.
- On an Internet-connected controller, you can use the **Get License** feature to automatically retrieve and load the license.
- When upgrading the software, the license key is migrated along with the other proofing configuration data.