

Adding an additional size to a substrate

A substrate is the surface that is printed on—for example, paper, carton, or plastic. The substrates available in Setup are loaded from the connected digital device. When you add a digital device in Setup, the device's substrates are automatically imported into the Substrate dialog box from the device. You can view the settings of a selected substrate in the right pane of the Substrate dialog box. The settings of the substrate are read-only and cannot be edited in Setup. However, you can add a size(s) to the selected substrate and [remove](#) a size(s).

1. In Workshop, from the **Tools** menu, select **Setup**.
2. In the left pane, click the arrow next to **Material**, to expand the **Material** section.
3. Click **Substrate**.
If substrates have already been added, a list of substrates is displayed in the center pane.
Click a substrate to view its settings (in the right pane).
4. To add a new size to the substrate, on the **Sizes** tab, click the **Add** button.
A new row is added to the list of substrates in the center pane.
5. In the new row, select the size that you want to add.
Note: The list of sizes is defined in **Resources > Size**. For details see, [Setting up a size](#).
6. On the toolbar, click .