

# Exporting plate or print curves

You can export a plate or print calibration curve, or calibration curves that are generated from a color setup.

In the Workflow and Pro Workflow editions of ColorFlow software, you do not need to export any color control elements in order to use them in your Prinergy Connect or Prinergy Evo workflow.

1. In the **Plate Curves** or **Print Curves** tab, find and select the curve that you want to export.
2. Click **Export**.
3. In the **Save Curves** dialog box, browse to the location where you want to save the curve.
4. Use the default file name for the curve or type a new file name, and click **Save**. The curve is saved in Harmony format, as a .hmy file.