


Using a P2P25 or P2P51 chart to characterize gray balance response

You can choose and measure the following P2P25 and P2P51 charts to characterize both tonal and [gray balance](#) responses:

- P2P25 i1iO or i1Pro
- P2P25Xa i1iSis
- P2P51 i1iO or i1Pro
- P2P25Xa i1iSis or i1iO

1. In a device condition, click the **Measurements** icon  next to a device.
2. In ColorFlow, in the **Charts** list of the **Device Measurement** dialog box, select the desired P2P25 chart.
3. Click **Export** and save the chart for printing.
4. Print the measurement chart using Prinergy.
5. [Measure the chart](#).