


Adjusting a color Input conversion

After you examine the separations that are produced by the CI, you can adjust the CI to PCO conversion DeviceLink to fine-tune the conversion. For example, you can adjust the input tonality of a single ink channel to modify how the ink channel is re-separated.

Note: Making a single-channel curve adjustment has a high impact because it changes the way separations are created for all output devices.

1. In the color setup viewer, click the **Conversion icon**  between the CI and the PCO.
2. From the **Input Version** dropdown list, select the desired version.
3. Select the **Conversion** Method.
4. Make the required adjustments, and click **Apply** to commit your changes.