

Editing tints in a plate curve

You can adjust the measured tint densities on plate after some changes have occurred to a plate line in an existing plate setup.

Note: You must have imaged a plate control strip using this particular combination of device type, plate type, screening, and plate line.

1. Click the **Plate Curves** tab.
2. Click the plate curve that you want to remeasure.
3. In the **Data** panel on the right, in the **Measured Plate Response** section, click the desired **Tint In** row and enter the measured plate response.
4. To modify the **Tint In** values, click **Tint Set** and make your changes.
5. Click **Apply**.