

# Using a P2P chart to characterize gray balance response

You can print and measure the following P2P charts to characterize both tonal and [gray balance](#) responses:

- P2P51 - i1iO or i1Pro
  - P2P51 - i1iSis or i1iO
  - P2P51 iSis mini
  - P2P25 - i1iO or i1Pro
  - P2P25Xa i1iSis
1. In a device condition, click the **Measurements** icon  next to a device.
  2. In ColorFlow, in the **Charts** list of the **Device Measurement** dialog box, select the a P2P51 (recommended) or P2P25 chart that supports your X-Rite measurement device.
  3. Click **Export** and save the chart for printing.
  4. Print the measurement chart using Prinergy.
  5. [Measure the chart](#).