Managing parameter settings



To create a new parameter set

In the Parameter Configuration interface, click the Save icon to save the Current Set as a **New Set**.

To open an existing parameter set

- 1. In the Parameter Configuration interface, click the Open icon on the panel to **Open Set**. The Open Set window appears.
- 2. Select the parameter set file from the list shown.
- 3. Click **OK**.

In the Parameter Configuration window, the current set name will change to Current Set: (name of the selected file)

Parameter Set Nam	e	
Untitled		
object		
	21	

To save a parameter set

Perform one of these actions

- In the Parameter Configuration interface, from the drop-down menu on the panel, select **Save Set**.
 - The update settings will be saved into the current parameter set.
- In the Parameter Configuration interface, from the drop-down menu on the panel, select **Save Set As**.

The file saving dialog box will be displayed. Enter a name into the text field and click **OK**. In the Parameter Configuration window, the current set name will change to Current

Set:	(name	of	the	curre	ent	file)
	Save	Set As	S			
Parameter	Set Name					
-						
Untitled						
object						
	ОК		Cance	21		

To export an old version parameter set

In the Parameter Configuration interface, from the side menu, select **Export old version parameter set**.

		•• х	
Parameter Configuration			Export old version parameter set
Ink			
Image	Enable Max Number of Allowed Spot Colors: 0		
Line	Max Number of Allowed Inks: 4		
Font	Varn on RGB Inks Usage		
Other			
Search			
Current Set: InspectP	araSet 🔽 🐲 📕 🧏 🕓		

To restore the modified current parameter set to the last saved set containing the original properties and parameters

In the Parameter Configuration interface, click the Reset icon.

