


# Importing measurement data

You can import [measurement data](#) that you previously saved for a device condition. The [measurement data](#) that you import must be in a .cgt file, CGATS.5 format, or .txt file. You can also import Current Curve or Target Curve tonal response measurements from a Harmony database file.

**Note:** To view tonal response or generate [tonal match](#) curve, the measurement data you imported must include spectral or density measurements.

1. In a device condition, click the Measurements icon .
2. Click the **Measurements** tab.
3. In the **Active Measurement** section, click **Import**.
4. Locate and select one or more files that contain the [measurement data](#) for your device condition, and then click **Open**.
5. If a previous measurement already exists for this device condition, click **Yes** to deactivate the previous measurement.