

Creating an Apply calibration curve hot folder

This hot folder applies the defined calibration curve to the incoming TIFF files.

General steps for creating a hot folder

1. Select **Tools > Hot Folder Setup**.
2. In the Hot Folder Setup dialog box, click .
3. Type a name for the hot folder in the **Hot Folders** list, and click anywhere in the dialog box.
4. In the **Input folder** box, click **Select**, locate and select the desired folder (if needed, click  to create a new folder), and click **Select**.
5. To define an output folder for the output TIFF file, click **Select** in the Output folder box, select an output folder, and click **Select**.
6. To delete the input files after the output file is created, select the **Delete input files after output** check box.

Setting up the Apply calibration curve hot folder

1. In the **Hot folder type** list, select **Apply calibration curve**.
2. In the **Calibration curve database** box, select the database of the Harmony calibration curves to apply to the incoming TIFF files. The files must have the .hmy file name extension to be recognized as calibration files.
3. In the table's **Calibration Curve** column, select a calibration curve for any of the separations.
4. Click **Save**.