

Digital Job Ticket Editor—Services tab

Note: Options on this tab may vary depending on the selected digital device. Some of the settings or setting values may not be available. Also, there may be additional settings available for specific devices which are not documented here.

The options in the Digital Job Ticket Editor are based on the capabilities of the selected device. When the Prinergy server connects to a digital device via Setup, the device communicates its capabilities in JMF format. The values for the different parameters are updated in the Setup application per device, and are reflected in the Digital Job Ticket Editor. The default value that was set on the digital device (and can be viewed in Setup) is used as the default value per parameter. If no value was set as default, the Job Ticket Editor displays **Device Default**. This selection can be changed.

When you define settings that are in conflict, these settings are marked with a red line around them, and when you hover above them, a tool tip displays what is wrong with the defined settings. You can also click the **Constraints** tab to see which settings you need to change in order to print the job.

Note: If you make a change in the Setup application while the Digital Job Ticket Editor is open, you must close and reopen the Digital Job Ticket Editor to see the change in the Digital Job Ticket Editor.

Store Job

Displays whether to archive the job, store it for a set time period and then delete it, or delete it after it is printed.

Send Email

Displays whether to send an email notification after job is printed, or after the job is printed or an error occurs.

If you select to send an email notification, type a valid email address in the **Send To** box, and type the message in the **Message** box.