Editing the ΔE Tolerance Thresholds

ΔE Tolerance Thresholds identifies the tolerance numbers for the selected media configuration file. The Precision Color Calibration wizard uses the **Current Average** number and the **Current Maximum** number when you calibrate the proofer for the media configuration. Spectrophotometer measurements taken during the Precision Color Calibration wizard are compared to the current tolerances set here.

	Average	Maximum	Standard
Default	<number></number>	<number></number>	ΔE94
Current	<number></number>	<number></number>	ΔE94

Kodak provides the **Default Average** number and the **Default Maximum** number for each media configuration to help you get started. You can change the default numbers to meet the needs of your shop.

- The **Average** column identifies the tolerance for the average color difference of all color patches measured with a spectrophotometer during the Precision Color Calibration wizard. You cannot accept a calibration when the average of the measurements is higher than tolerance number identified in the **Current Average** box.
- The **Maximum** column identifies the tolerance for the largest color difference of all color patches measured with a spectrophotometer during the Precision Color Calibration wizard. You cannot accept a calibration when the largest color difference measured is higher than tolerance number identified in the **Current Maximum** box.
- The **Standard** column identifies the color measurement standard used for the calculations.

The Precision Color Calibration wizard always uses the Δ E94 standard. You cannot change to another standard, such as Δ Eab.

Increase a value to loosen the tolerance, or decrease a value to tighten the tolerance.

- Larger tolerance numbers take less time to calibrate a proofer, but the proofer reproduces color less consistently.
- Smaller tolerance numbers ensure that the proofer reproduces color consistently, but when a tolerance number is too low, it may be difficult to calibrate the proofer.

Note: You can also change the thresholds in the Precision Color Calibration wizard when performing a calibration.

To edit the ΔE Tolerance Thresholds

- 1. In Proofer Viewer, from the **Configure** menu, select **Media Configuration**.
- 2. Select a media configuration, and click Edit.
- 3. Click the **Calibration** tab.
- 4. Click Change.
- 5. When prompted, type your administrator password, and click **OK**. The default password is prooferAdmin.
- 6. In the area's **Current** row, type the desired **Average** and **Maximum** values.
- 7. Click Save.