

Changing the wait time for color bars

You can define how long the software waits for the ink to dry before measuring the color bar for the Certified Process for Color Confirmation.

Requirement: The color bar must have an **Origin** of **Customer**.

1. In Proofer Administrator, click the **Proofer** icon, and click the **Color Bars** tab.
2. Select the color bar, and click **Edit**.
3. Click **Advanced**.
An information dialog box appears.
4. Click **OK**.
5. Click the **Settings** tab, and, in the **Drying Time** area, specify how long to wait for the ink to dry.
6. Click **Save**.