

Viewing the response type of a device condition

After you have [characterized the color response](#) of a device in a device condition, you can view its color response type in the **Process Inks Response Type** column in the **Measurements** tab of the **Measurements** dialog box.

The following table descriptions each color response type:

Response type	Description
Tonal only	Obtained by measuring a Tint Ramp or Tonal only chart . Supports only Tonal Match calibration curve generation.
Gray Balance only	Obtained by importing a P2P chart measurement that does not contain density or spectral measurement data. Supports only Gray Balance calibration curve generation.
Gray Balance and Tonal	Obtained by measuring a P2P chart . Supports Tonal Match and Gray Balance calibration curve generation.
Full Color and Tonal	Obtained by measuring a Full Color and Tonal chart . Supports all calibration curve generation methods and device profile and DeviceLink generation.
Full Color only	Obtained by importing a Full Color and Tonal chart measurement that does not contain density or spectral measurement data. Supports only Gray Balance calibration curve generation, and device profile and DeviceLink generation.